

# ProSheeter 1600

Technical Support Bulletin

## Setup Instructions for tracking

Abstract: This technical support bulletin shows the material loading instructions for the ProSheeter to allow the media to track straight. Last Update March 19, 2007.

- 1) Loosen the two donuts and move them away from the media.
- 2) Put on a new roll of media to sheet, thread the media through the input track as shown to the right and bring in straight into the pinch rollers.
- 3) Advance media infeed to allow some slack 2-3 feet of slack.
- 4) Use the jog button on the ProSheet to feed about 2 feet of media. The media will then align itself with the infeed roll.
- 5) Move the two tracking donuts to almost touch the media (about 1/16 inch).
- 6) Adjust the SmartMark position to point to the middle of the mark.

Donuts

Adjust left/right position of eye by loosening this nut and sliding assembly left or right.

