



Technical Support Bulletin (Last update 7-19-6)

Single Button Contour Sheet Copy

Abstract: If you are contour cutting on sheet media you can set up a sequence where you can load a sheet and press one button to cut the contour on the sheet loaded without positioning the Smartmark sensor over the target on each sheet. Just raise the pinch wheel, insert media, press button and it starts the job.

Requirements:

- Each sheet must be printed identical to every other sheet.
- Paper sensors must be on and working (setup -> options)
- Media height sensor must be on and working (setup -> options)
- Load length must be set greater than media movement length of paper (setup -> settings). Make change and then click on save settings and OK.

Operation:

- Load first sheet of set
- Joystick backward until knife blade is in front of origin mark
- Press load button (scans left/right, then finds rear edge of media)
- Move Smartmark sensor to lower right of origin target
- Send cut lines from computer to cutter
- Wait for job to complete
- Remove first sheet and load next sheet same orientation as first sheet. You do not need to align the target.
- Press F2 key on cutter then copy key. Cutter will find rear edge of media, move to the target and cut the job on 2nd sheet.
- Sheet will be dropped out the back of the machine upon completion
- Load next sheet
- Press copy button
- Load next sheet
- Press copy button